


SESAME

PUSH | DRUCKTASTER | POUSSOIR | PULSADOR


EN Getting started DE Erste Schritte FR Démarrage NL Aan de slag FI Aloitusopas DK Kom i gang
IT Operazioni preliminari ES Para empezar PT Para começar GR Πρώτα βήματα SE Kom igång

D814


1



2



3



1-24V 2A



EN Trouble shooting DE Fehlerbehebung FR Dépannage NL Probleemoplossing FI Vianmääritys
DK Problemløsning IT Risoluzione dei problemi ES Solución de problemas PT Resolução de problemas
GR Αντιμετώπιση προβλημάτων SE Felsökning

livewell.honeywell.com