



	1	265995-6	TAPPING SCREW 4X18	5 PC.
	2	451619-2	TOP COVER	1
	3	265995-6	TAPPING SCREW 4X18	2 PC.
	4	645105-5	NOISE SUPPRESSOR	1 PC.
	5	687052-4	STRAIN RELIEF	1 PC.
	6	682502-4	CORD GUARD 8-85	1 PC.
	7	665383-1	POWER SUPPLY CORD 1.0-2-2.0	1 PC.
	8	191627-8	CARBON BRUSH CB-64	1 SET
	9	643552-4	BRUSH HOLDER 5-8	2 PC.
	11	651286-5	SWITCH SGEL206C-5	1 PC.
	12	263002-9	RUBBER PIN 4	2 PC.
	13	451617-6	MOTOR HOUSING	1
	14	867887-1	BO5041 NAME PLATE	1 PC.
	15	633724-9	FIELD 240V	1
	16	266147-2	TAPPING SCREW 4X55	2 PC.
	17	210017-7	BALL BEARING 607DDW	1 PC.
	18	681652-2	INSULATION WASHER	1 PC.
	19	515734-7	ARMATURE ASS'Y 240V	1 PC.
	19		INC. 17182021	0
	20	267806-1	WASHER 9	1 PC.
	21	211092-6	BALL BEARING 629DDW	1 PC.
	22	450672-5	BRACKET	1 PC.
	23	265995-6	TAPPING SCREW 4X18	4 PC.
	24	241673-2	FAN 88	1 PC.
	25	267164-5	FLAT WASHER 15	1 PC.
	26	188835-0	SKIRT SET	1
	26		INC. 28	0
026A		188835-0	SKIRT SET	1
026A			INC. 28	0
	27	265995-6	TAPPING SCREW 4X18	2 PC.
	28	188835-0	SKIRT SET	1
	28		INC. 26	0
028A		188835-0	SKIRT SET	1
028A			INC. 26	0
	29	318304-9	BEARING BOX	1 PC.
	30	211228-7	BALL BEARING 6202DDW	1 PC.
	31	424131-5	BRAKE RING	1 PC.
	32	318303-1	BEARING BOX COVER	1 PC.
	33	253739-6	FLAT WASHER 4	1 PC.
	34	911128-8	PAN HEAD SCREW M4X16	1 PC.
	35	743081-8	PAD 123	1 PC.
	36	911128-8	PAN HEAD SCREW M4X16	3 PC.
	37	631956-2	CONTROLLER	1
A01		125779-3	GRIP ASSEMBLY	1
A01		140440-1	GRIP BASE COMPLETE	1
A01		451622-3	GRIP	1
A01		451623-1	GRIP COVER	1
A02		135246-0	DUST BOX ASSEMBLY	1 PC.
A02			INC. A03-A06	0
A03		450770-5	DUST BOX	1 PC.

A04	450769-0	DUST NOZZLE	1 PC.
A05	424144-6	RUBBER SLEEVE	1 PC.
A06	232246-2	LEAF SPRING	2 PC.
A07	794544-7	ABRASIVE DISC 125 #120	1 SET
A07A	794544-7	ABRASIVE DISC 125 #120	1 SET
A08	824562-2	PLASTIC CARRYING CASE	1 PC.
A08	416661-0	LATCH	2 PC.