



CleanSpace® AGILE Half Facepiece (inc. CleanSpace® Fabric Head Harness*)

* Refer to CleanSpace CST1037 Fabric Head Harness Data Sheet.



PRODUCT CODE	CSA4018 (One Size)
PRODUCT NAME	CleanSpace AGILE Half Facepiece (including CleanSpace Fabric Head Harness)
DESCRIPTION	A CleanSpace AGILE Facepiece (includes a CleanSpace Fabric Head Harness CST1037) is certified and designed for use with the CleanSpace AGILE Power Unit (CSA4001). <u>The CleanSpace AGILE Facepiece is NOT certified for use with any other PAPR in the CleanSpace range.</u> It has two main components, the Mouthpiece and the Bib. These come apart for cleaning or bib replacement. The clips quickly and securely attach the Facepiece to the Power Unit. The exhalation valve is housed on the right hand side of the mouthpiece behind an accessible cover. The bib has a frame that secures to the mouthpiece. The CleanSpace Fabric Head Harness attaches to connection points on the Facepiece and can be removed for cleaning.
APPROVALS	Standard & Classification EN12941: 2023 TH2
FEATURES	• Certified TH2 (loose-fitter) – no fit testing required. Suitable for use by workers with facial hair • Lightweight, comfortable and durable • Soft silicone nose piece that readily moulds with the face for a comfortable fit • One size fits all • Transparent mouth piece to assist with communication • Removable exhalation valve for cleaning
SPECIFICATIONS	• Facepiece Product Weight: 148g (approx) • Head Harness Product Weight: 29g (approx) • Facepiece & Head Harness Packaged Dimensions (One Size): 200mm x 170mm x 140mm (approx)
MATERIALS	Silicone Nosepiece Nylon Clips Polycarbonate Mouthpiece (with exhalation valve seat) Silicone Leaf Valve Neoprene Bib Nylon Frame Stainless Steel Screws (x2) (Head Harness Materials: Polyester Elastic Nylon Clips High Strength Silicone Rear Strap)
STORAGE & DISPOSAL	• Store away from direct sunlight, grease and oil • Used components may have been exposed to hazardous materials and should not be considered recyclable. Dispose of used components in line with company and local authority regulations





CLEANING

- Hand wash in warm (< 50°C) soapy water and rinse
- Do not use solvents, hot water, bleaching or chemical agents
- After cleaning allow to air dry or wipe dry with a clean lint free cloth

Note 1: Refer to Supplements for compatible cleaning products and industrial washing processes.

LIMITATIONS

CleanSpace respirators are air filtering, fan assisted, positive pressure systems and designed to be worn in environments where there is sufficient oxygen to breathe safely. Do not use CleanSpace AGILE in environments that are immediately dangerous to life or health (IDLH), to protect against gases/vapours, or in oxygen enriched or deficient atmospheres.

EDUCATION

Contact sales@cleanspacetechnology.com or visit the [CleanSpace website](https://www.cleanspacetechnology.com) for details.

WARRANTY

Visit www.cleanspacetechnology.com/warranty to read important Warranty information. Consumable parts are warranted up to the point of use, provided they have been stored correctly and are within their expiry date.

